



## Product Information Sheet:

### Pourable Drive Repair

25kg



Floorsaver Pourable Drive Repair delivers fast, high-strength repairs for asphalt and Tarmac making it ideal for driveways, paths and loading bays. Just mix with water and pour into holes, cracks or worn areas.

- Fills holes 5mm to 100mm deep in one go
- Just mix the powder with water and pour into the repair.
- Takes lorry and forklift traffic in just 4 hours
- Ready for foot traffic after just 1 hour
- High strength polymer and cement blend formulation
- For internal or external use

#### HERE'S HOW TO USE IT:

##### Step 1 - Preparation:

- Minimal prep is needed. Sweep with a stiff broom to remove loose debris. The area can be damp (not wet), and no primer is required.
- In heavy-wear areas, thin feather-edge repairs can fail. If edges are under 5 mm deep, chip back the asphalt so the repair is at least 5 mm thick.

##### Step 2 - Mixing:

- Remove the bag of powder from the bucket.
- Mix 1 part powder to 3 parts water, measuring with an old cup or similar. Start with a small batch until you're familiar with it, as once mixed it must be used within 10 minutes.
- Pour the water into the bucket provided, or a similar mixing vessel.
- Add the powder gradually while mixing continuously; a drill-mounted mixing blade is recommended, especially for larger mixes.
- Mix in powder until you get a pourable slurry (like runny porridge). If it's too stiff, add a little more water; if it's too runny, add more powder.
- Use immediately and don't re-stir once you have stopped.

##### Step 3 - Application

- You have up to 10 minutes to pour the mix. It can be applied up to 100mm deep at once. For deeper repairs, apply in 100mm layers and allow 12 hours to dry between layers.
- For patch repairs or resurfacing, use a trowel to spread it evenly. If mixed correctly, it will self-smooth.
- 25kg covers approximately 0.5m<sup>2</sup> at 25mm thick.
- Clean tools in water.
- The repair can be painted if required.

#### DRYING TIMES (AT 10°C):

|               |                                                                             |
|---------------|-----------------------------------------------------------------------------|
| INITIAL SET   | Dries quickly so only mix what you can use within 10 minutes.               |
| FOOT TRAFFIC  | 1 hour                                                                      |
| HEAVY TRAFFIC | Vehicles and forklifts - 4 hours                                            |
| PAINTING      | Allow 12 hours if you want to paint over the repair. At 5°C allow 24 hours. |

#### SHELF LIFE:

12 months, if unopened and should not be allowed to freeze.

#### WE DON'T RECOMMEND:

- Using at temperatures below 5°C.
- Using on slopes, step nosings, etc. since the product is pourable.
- Using at a depth of more than 100mm in one go. For very deep holes, allow a 100mm thick layer to dry for 12 hours, at a minimum temperature of 10°C, before applying the next.

#### SAFETY:

- Material Safety Data Sheets are available.
- Product labels provide general safety information.

#### ORDERING:

Please place your order direct from us online using a debit or credit card. We want you to enjoy using our products and achieve a really good result.

If you have any comments or need advice, please contact us using the details below.

#### Sales & Technical Support

UK: 0345 450 9888

IE: 0818 543 250

info@floorsaver.co.uk

info@floorsaver.ie

floorsaver.co.uk

floorsaver.ie